



Materials list:

- ICE Resin
- Calibrated mixing cup and stir stick
- ICE Resin Paper Sealant
- ICE Resin Studio Sheet
- ICE Resin Angled Paintbrushes
- Imagery

Directions:

1. Cut desired image and/or word to fit inside bezel.
2. Brush Paper Sealant onto the front, back and edges of image(s). Place inside bezel. Set aside to thoroughly dry.
3. Add any inclusions to bezels, such as a small amount of glass glitter or charms.
4. Pour equal parts of Part A Resin and Part B Hardener in a calibrated mixing cup.
5. Using a gentle stirring motion, begin mixing the two parts together in the cup. After about 30 seconds on stirring, gently move to a “folding” motion (like mixing egg whites) to fully integrate the two parts. Be sure to scrape down the sides of the cup as well to full mix.
6. Set mixed resin aside for 5 minutes to allow the bubbles caused during mixing to rise to the cup’s surface and dissipate.

7. Use you stick to slowly drip mixed resin into your bezel with the sealed image and inclusions. Fill until just below the top of the bezel. If you wish to dome your bezel, slowly continue to drip resin into bezel until you see the natural dome form. Be sure to stop before over pouring.
8. Set bezel aside 6 to 10 hours to cure to the touch. Resin will feel smooth with a glasslike surface when it's dry.

To learn more about Susan Lenart Kazmer ICE Resin visit our website at ICEResin.com.

Susan Lenart Kazmer ICE Resin products manufactured and sold by Ranger Ink. To learn more visit Ranger's website at RangerInk.com.

