

MULTIPLIERS

(SINCE THIS ISN'T REALLY A "PROJECT" THE INSTRUCTIONS MAY BE A BIT STRANGE, THIS IS PART OF THE THREE SHORT MINI-TIPS FOR SPEED BEADING AND WIRE WRAPPING)

1. Assemble some beads that have the appropriate diameter holes for 22Ga (or other diameter) German Style Wire. I like using German Style Wire because it has a tensile close to half-hard so the wire stays put once bent.
2. Hold the MultiPliers in your dominant hand with the round nose tips pointing up to your eyes, this will cause the Chain Nose tips to be pointed away from your body.
3. Make a loop on the round portion of the Round Nose Plier tip with the 22Ga Round Wire, that is the appropriate size loop (determined by you) for the wire wrapping project you are making.. Wrap a complete loop using the short end of the wire leaving enough for wrapping the longer wire.
4. Remove the loop from the Round Nose and move it directly to the Chain Nose tips, grasp 2/3 of the loop with the tips and wrap the short end around the neck of the loop as many wraps as you deem appropriate.
5. Put a bead onto the long portion of the wire and snug it up to the previously wrapped loop, use the long wire to wrap a loop just far enough from the bead to accommodate the same number of wraps done on the first loop.
6. Pass the loop from the Round Nose Tip to the Chain Nose tip as in step 4 and complete the wrapping of the neck of the wire.
7. Cut the ends of the wrapped wires flush against the coil, then repeat steps 2-7 until the "chain" has been completed.

List of items used

201C-010	MultiPliers
180B-022	GERMAN STYLE 22GA ROUND WIRE TRSP
.... OR	
180A-022	GERMAN STYLE 22GA ROUND WIRE TRGC
	FLUSH CUTTER
	BEADS

